

· Field Effect Transistors (FET):

- The field-effect transistor (FET) is a semiconductor device with the output current controlled by an electric field.
- In FET the current is carried predominantly by one type of carriers, thus the FET is known as unipolar transistor.
- The FET is thus different from the bipolar junction transistor (BJT) which involves two types of carriers (electrons and holes) for current conduction.
- · FET are used in controlled switching between Conducting and nonconducting states in a digital Circuits. FETs are also thermally stable.



The JFET consists of a uniformly doped Semiconductor base usually of Silicon (Si) or Gallium arsenide (GaAs). If the semiconductor bax is n-type, the JFET is called on-channel JFET, on the other hand if the bax is p-type, the device is termed a p-channel JFET.



Two sides of the box are heavily doped with imputities opposite to that of the box. (i.e. p-type imputities for an n-type box and n-type imputities for an p-type box.). By applying a voltage VDD between the two ends of the box a convent is allowed to flow along the length of

Source (3): The terminal through which the majority Cooviers enter the box is known as source.

the bax.

Drain (D): The terminal through which the majority Casovers leave the base is known as drain.

Crate (G): The region on the two sides of the box heavily doped with impurities opposite to the box is called Gate.

Principle of JFET Operation:


The junction between the bax and the gate is reverse biased by applying a voltage Vag. The resulting depletion regions extends into the bax. The width of the depletion region can be controlled by changing the gate—to-Source voltage. The depletion region does not have any current corriers, so that the conductivity of these regions is nominally zero. Therefore, the effective cross Sectional area through which the current flows in the bar decreases with increasing reverse bias. For a given drain—to-Source voltage, the drain current is a function of the gate—to-Source voltage.

The JFET is basically a voltage - controlled resistor, the resistance being controlled by the gate voltage.

The partion of the Semiconductor bour between the depletion region through which the majority Coowiers move from Source to drain is called the channel.

Static Characteristics of JFET:

The graphical plots of the drain current (ID) against the drain-to-Source voltage (Vos) with the gate-to-Source voltage (Vas) as a parameter are Known as Static characteristics of JFET.



The drain characteristics are found to consist of three regions,

- i) The linear region, where the voltage VDs is small and ID is nearly proportional to VDs.
- The saturation region where ID is fairly constant and is independent of v_{DS}
- with a Small increase of V_{DS} .

The constant drain current in the saturation region of the characteristics is called the saturation current (Issat). The minimum value of VDs at which

the drain current saturates for a given Vgs is called the Saturation voltage Vosat. The points of intersection of the dashed curve with the characteristics give the values of I Dsat and VDsat for different Vgs.

Pinch off voltage:

Pinch off voltage is the drain to source voltage of ter which the drain to source current becomes almost constant and JFET enters into saturation region.